









Quick Reference Guide

MiVoice 5330e IP Phone





- | | | |
|---------------------------------|-------------------------------------------------------------------------------------|---------------------|
| 1 Display |  | Speaker |
| 2 Ring/Message Indicator |  | Mute |
| 3 Volume, Speaker/Mute Controls |  | Menu |
| 4 Fixed Function Keys |  | Cancel |
| 5 Keypad |  | Redial |
| 6 Page Navigation Keys |  | Hold |
| 7 Personal Keys |  | Transfer/Conference |
| 8 Speaker |  | Message |
| 9 Handset | | |


¹ Brightness Control is available on backlit display models only.

Note: For more information about other features and applications on your 5330e IP Phone, refer to *5330e/5340e IP Phone User Guide* located at www.mitel.com, or contact your Administrator.


Make a Call

- 9 Lift the handset OR
- 3 Press .
- 5 Dial the number OR
- 7 Press a **Speed Call** key OR
- 4 Press  OR
- 5 Dial the prefix for external calls (e.g. 9) and the number.


Answer a Call

- 9 Lift the handset OR
- 3 Press , and begin speaking.


End a Call

- 4 Press  OR
- 9 Replace the handset.


Place a Call on Hold

- 4 Press . The line key flashes.
- 9 Replace the handset if necessary.


Retrieve a Call from Hold

- 9 Lift the handset OR
- 3 Press .
- 7 Press the flashing line key.



Retrieve a Message

- 4 Press . It flashes when a message is waiting. Follow the voice mail prompts to retrieve your message.


Transfer a Call

- 4 Press .
Dial the number. Wait for an answer.
Hang up OR announce the transfer and then hang up.

Conference a Call




- 4 Press .
- 5 Dial the number. Wait for an answer.
- 4 Press .

Program a Speed Call

- 4 Press **Menu** OR .
Press **Settings**.
Press **Programmable Keys**.
Press the key you wish to program.
Press **Speed Call**.
Press **Edit Info** and enter the label for the Speed Call.
Press **Save**.
Press **Edit Number** and enter the phone number for the Speed Call.
Press **Save**, and then press **Save** again.
Press **Close** and then press **Close** again.

Adjust Volume Levels

Adjust ringer volume while the phone is ringing. Adjust handset or speaker volume while using the handset or speaker.

- 3 Press  repeatedly to raise the volume OR  repeatedly to lower the volume.
- 3 Press  to mute your microphone.